



1911 COMPACT

Installation Instructions

Note: For use with the Compact and Officer size 1911's and other 1911 clones. The grip screw placing for these and other compatible models is 2 1/16" inch apart.

- 1- Put on eye protection. Remove the magazine and check that the firearm is unloaded before installation.
- 2- Remove the grip screws and the grip plate.
- 3- Install the Techna Clip on the right-side of the gun by aligning it with the grip holes.
- 4- Replace grip and tighten with original screws.

