



1911 FULL SIZE

Installation Instructions

Note: For use with the Full Size, Government, Commander, Standard Frame 1911's and other 1911 clones. The grip screw placing for these and other compatible models is 3-1/16" inch apart.

- 1- Put on eye protection. Remove the magazine and check that the firearm is unloaded before installation.
- 2- Remove grip screws and grip plate.
- 3- Install Techna Clip on right-side of gun by aligning it with the grip holes.
- 4- Replace grip, and tighten with original screws.

