



KEL-TEC P-3AT

Installation Instructions

- 1- Put on eye protection; remove the magazine and check to see that the firearm is unloaded before installation.
- 2- Remove rear frame pin by gently tapping it with punch and mallet.
- 3- Insert binding post in place of rear frame pin by lightly tapping the binding post in with a mallet. (Excessive force may cause damage to gun).
- 4- Put provided screw through hole of the clip and tighten screw into binding post with the provided allen key. (Please note that the clip hole may be slightly off centered from the binding post hole)
- 5- Make sure clip is seated properly around the edge of firearm. Before use, check to make sure that all functions of the firearm work properly and that you can handle the firearm safely.

