



S&W BODYGUARD

Installation Instructions

1. Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.
2. Tap out the rear frame pin from the right-side with a mallet by using the provided binding post or dowel punch. Please note, in order for the binding post to properly go through frame of the gun, the composite section of the hole must align with the metal section of the hole. (Excessive force may cause damage to gun and binding post.)
3. Put provided screw through the hole of the clip and tighten the screw into the binding post with provided allen key. (Please note that the clip hole may be slightly off centered from binding post hole.)
4. Make sure clip is seated properly around the edge of the firearm. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.

