



S&W J FRAME

Installation Instructions

- 1- Put on eye protection, remove the magazine and check that the firearm is unloaded before installation.
- 2- Remove the two screws that are directly above and to the left of the trigger.
- 3- Place the Techna Clip on the frame of the gun with screw holes aligned.
- 4- Fasten the two screws with the allen key provided.
- 5- Make sure the clip is seated properly around the edge of the firearm. Before use, check to make sure that all functions of the firearm work properly and that you can handle the firearm safely.

