



SIG SAUER P938

Installation Instructions

- 1- Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.**
- 2- Remove grip plate by unloosening the grip screws with allen key.**
- 3- Place Techna Clip on the frame of the gun with screw holes aligned.**
- 4- Align grip plate to the Techna clip and fasten with provided screws. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.**

