



Springfield XDM & XD MOD.2

Installation Instructions: FITS ALL XDM & XD MOD.2 MODELS

1. Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.
2. Remove slide from the frame of the gun, then separate the barrel from the recoil spring. Refer to the XDM or XD MOD.2 Operations and Safety Manual for this step.
3. Using a dowel punch depress the striker spring guide. While the striker spring guide is depressed, remove the striker locking plate. This is done by, using your thumb to push the striker locking plate down.
Warning: The striker spring guide is spring-loaded and can spring out if your not careful.
4. Install the provided striker locking plate by depressing the striker spring guide with a dowel punch and inserting the striker locking plate at the same time. Then attach the slide to the gun. Refer to the XDM or XD MOD.2 Operations and Safety Manual.
5. Attach the clip to the backside of the striker locking plate with the provided screws and Allen key. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.

