



## BERETTA NANO

### Installation Instructions

- 1- Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.
- 2- Remove slide from the frame of the gun. Refer to the Nano instruction manual for this step.
- 3- With small punch, push the rear assembly pin out of the frame and replace it with the provided pin by, lifting the cocking lever spring and seating it in the groove of the rear assembly pin while pushing the new pin in. (Do not force the rear assembly pin through hole, it may cause damage to gun.)
- 4- Insert the provided screw into the hole of the clip, and tighten screw into binding post with provided allen key. Please note, that the hole in the clip, and the treaded hole on rear assembly pin, is slightly off centered. This causes tension and helps keep the clip from rotating while in use.
- 5- Check to make sure clip is seated properly around the edge of firearm.
- 6- Assemble the slide to the frame. Refer to the Nano Instructions Manual for this step. Before use, check and make sure that all functions of the firearm are working properly, and that you can handle the firearm safely.

