



GLOCK 42

Installation Instructions

1. Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.
2. Remove slide from the frame of the gun, then separate the barrel from the recoil spring. Refer to the Glock Instructions Manual.
3. Using a dowel punch, push down the plastic spacer sleeve to remove the slide cover plate. Once depressed, push down the slide cover plate with your thumb while depressing the plastic spacer sleeve.
4. Install the provided slide cover plate by pushing down the plastic spacer sleeve and push the slide cover plate into the slide. Then attach the slide to the gun. Refer to Glock Instructions Manual.
5. Attach the clip to the backside of the slide cover plate with the provided screws and allen key. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.

