



Ruger LC9 & LC

Installation Instructions

- 1- Put on eye protection, remove the magazine, and check that the firearm is unloaded before installation.
- 2- Remove rear frame pin by gently tapping it with a punch and a mallet.
- 3- Insert binding post in place of frame pin by lightly tapping frame pin in with a mallet. (Excessive force may cause damage to gun.)
- 4- Put provided screw through hole of the clip and tighten screw into binding post with provided allen key. (Please note that the clip hole may be slightly off centered from binding post hole.)
- 5- Make sure clip is seated properly around the edge of the firearm. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.

