



**COMPATIBLE WITH THE RUGER LCP II**  
(NOT COMPATIBLE WITH THE RUGER LCP, LC9/S, LC)

## Installation Instructions

1. Remove the magazine and check that the firearm is unloaded before installation.
2. Remove the rear frame pin by tapping it out with a punch and a mallet.
3. Insert the new frame pin in from the left slide by tapping pin in with a mallet. (Excessive force may cause damage to gun)
4. Attach the Techna Clip® to the right side of the gun with the provided screw and allen key. Note, that the screw hole in the clip may be slightly off centered from frame pin to provide a secure attachment.
5. Make sure clip is seated properly around the edge of the firearm. Before use, check to make sure that all functions of the firearm work and that you can handle the firearm safely.